Business Furniture Online Ltd.
for all your office furniture needs

Titan - Operating Instructions

(Synchro mechanism)

Height Adjustable Back
Lift back to adjust in 9 steps. (on a ratchet). Lift to the top and lower to start again.

Height Adjustable Armrest (Optional)
Press button and raise or lower armrest. Release button.

Tension Control Knob (Rear Right)
Turn knob clockwise to increase tension and anti-clockwise to decrease tension. The looser the tension the more easily the chair moves when user is seated.

Seat Slider (optional)
Where fitted this lever will be located in front of seat height adjustment lever.
Lift front right handle and slide seat forward or back. Release lever to lock into position.

Tilt Lock Adjustment Lever (Front Lever)
To adjust sitting position push in button. Lean back into seat to release back and allow backrest to move to desired position. Push button again to lock back in position or leave to allow seat and

Seat Height Adjustment Lever (Front Lever – same lever as Tilt Lock)
Lift lever whilst remaining seated to reduce height of seat. Release lever in desired position.
Lift lever and raise body weight from seat to allow seat to rise automatically. Release lever to lock seat in desired position.

All instructions are given from a seated position.

(October 2010)